



### ADA/ICC INSTALLATION GUIDANCE

**\*Operable Part:** Toilet tissue dispenser opening on the bottom of the cabinet.

**Mounting location of Operable Part:** ADA 15" minimum (380mm) above finished floor (AFF). Centerline of dispenser located 7" to 9" (180mm to 230mm) in front of leading edge of toilet. ICC 18" minimum (455mm) above finished floor (AFF). Dispenser outlet located 24" to 42" (610mm to 1065mm) from rear wall.

### FINISH VARIATIONS

Stainless Steel Satin <b>BAGNO-133-3</b> Stainless Steel Satin (AFP*) <b>BAGNO-133-1</b>	Gold Antique (AFP*) <b>BAGNO-133-11</b>
Stainless Steel Antique (AFP*) <b>BAGNO-133-7</b>	Matte Black (Texture) <b>BAGNO-133-13</b>
Gold (AFP*) <b>BAGNO-133-9</b>	Rose (AFP*) <b>BAGNO-133-15</b>

\* AFP : Anti-FingerPrint

NOTE : All surface variations have brushed satin finishes except Matte Black

### MATERIALS:

The product material is **STAINLESS STEEL Type-304** and exposed surfaces feature a satin (brushed) finish. The body thickness of the dispenser is 0.6mm. Viewing Slot shows toilet tissue supply inside dispenser. Equipped with a lock keyed.

**Core Adapter :** One (1) 10" (254 mm) jumbo roll of toilet paper is mounted over 2-1/4" (57 mm) core adapter. One (1) 1-5/8" (41.3 mm) core roll may be used by removing the rubber core adapter.

### OPERATION:

Door unlocks with key provided and swings down for loading dispenser.

One (1) 10" (254mm) jumbo roll of toilet paper is mounted over 2-1/4" (57mm) core adapter. One (1) 1-5/8" (41.3mm) core roll may be used by removing the rubber core adapter.

Viewing slot reveals the amount of toilet tissue on roll.



## Technical Data

# SURFACE-MOUNTED TOILET TISSUE DISPENSER

## BAGNO-0133

### INSTALLATION:

Mount unit on wall or toilet partition with sheet-metal screws at points indicated by an S.

For plaster or dry wall construction, provide concealed backing to comply with local building codes, then secure with sheet-metal screws. (not provided by manufacturer).

For other wall surfaces, provide fiber plugs or expansion shields for use with sheetmetal screws (not provided by manufacturer).

For partitions with particle-board or other solid core, secure with sheet-metal screws (not provided by manufacturer), or provide through-bolts, nuts, and washers.

For hollow-core metal partitions, provide solid backing into which the sheet-metal screws can be secured.

If two units are installed back-to-back, then provide threaded sleeves and machine screws for the full thickness of partition.

### SPECIFICATION:

Single jumbo-roll toilet tissue dispenser is is 0.6 mm stainless steel with satin-finish.

Dispenser equipped with a lock keyed.

Dispenser has a slot to reveal toilet tissue supply inside cabinet.

One (1) 10" (254mm) jumbo roll of toilet paper is mounted over 2-1/4" (57mm) core adapter.

One (1) 1-5/8" (41.3mm) core roll may be used by removing the rubber core adapter.